



### Fitting SAC Flush Access Cover

1. Remove all packaging & band straps.
2. Check size of structural opening and recessed dimensions against overall frame sizes to determine packing/grout requirements to ensure top of frame will be flush with floor level.
3. Check rebate is sufficient for frame.
4. Layer bottom of structural recess with suitable packing/grout.
5. Using slings if necessary lower access cover into recess. Line up the drainage fitting if fitted and connect drainpipe as required.
6. Check top of frame is flush with floor level and frame is not twisted.
7. Check gas spring bracket(s) are flush with inside of hole. Pack if necessary. It is important that the lower gas spring bracket(s) are flush against the inside of the opening.
8. Fix frame in position and back fill as required. Allow the back fill to set.
9. If gas springs have been removed for transit, re-attach gas springs in accordance to gas spring fitting instructions.
10. Check access cover by open and closing lid, the brass screw will need to be removed so the 'Tee' key can be inserted into the cablock.
11. Please remember to replace the brass screw after closing the lid.

For further information contact:

Surespan Limited

Leamore Close

Leamore Enterprise Park

Walsall

West Midlands

WS2 7NL

Tel: +44 (0)1922 711185

Fax: +44 (0)1922 714099

Email: [sales@surespancovers.com](mailto:sales@surespancovers.com)

