

## VLE VERTICAL ROOF VENTILATOR

1. Check structural opening size with clear opening size of access cover.
2. Place Roof Hatch in position and fix down with 8mm anchor bolts. IF fire rated it is recommended that you use a fire resistant mastic for sealing the frame to the concrete.
3. It is important that you do not try to open the lid before being securely fastened down as the frame may open very fast.
4. The gas spring brackets that are bolted to the frame should always be packed up if there is a gap behind them. This only applies if the brackets are protruding past the frame into the structural hole.
5. When cover is fixed into position, try opening the lid via square 'Tee' key, handle or any device that you have requested to be fitted.
6. One person should easily open the lid without any real effort applied.
7. There is a lip incorporated into the frame for use of flashing and making water tight.

